


# How to Assemble the 4WD Car Chassis

#### **Table**

| 1. | Parts List2                            |
|----|--|
|    | 1.1 Connecting/Fixing Parts2           |
|    | 1.2 Tool                               |
| 2. | Assemble and Install5                  |
|    | 2.1 Assembly steps5                    |
| 3. | Make your suggestion and get support18 |



## 1. Parts List

## 1.1 Connecting/Fixing Parts

| Picture  | Name  | Description                  | Qty |
|----------|-------|------------------------------|-----|
| (f)      | screw | M3*10MM round screw          | 28  |
| <b>4</b> | screw | M3*25 countersunk head screw | 9   |
|          | screw | M3*8 countersunk head screw  | 3   |
|          | screw | M3*8 round screw             | 4   |
|          | nut   | M3 nut                       | 10  |
|          | nut   | M3 self-locking nuts         | 9   |

|  | copper pillar | M3*20 double pass copper pillar         | 4 |
|--|---------------|---|---|
|  | copper pillar | M3*10 double pass copper pillar pillar  |   |
|  | copper pillar | M3*30MM double pass copper pillar       | 4 |
|  | copper pillar | M3*45 double pass copper pillar         | 4 |
| IN TAN OF THE SHAPE STATE OF THE | battery case  | 18650 battery case                      | 1 |
|  | motor         | TT motor-dual axis reduction ratio 1:48 | 4 |
|  | bracket       | TT motor metal bracket                  | 4 |

| wheel                 | TT motor wheel       | 4 |
|-----------------------|----------------------|---|
| acrylic<br>structural | 4WD car base acrylic | 1 |
| parts                 | structural parts     |   |

### **1.2 Tool**


| Picture | Name        | Description             | Qty |
|---------|-------------|-------------------------|-----|
| 3 5 G   | wrench      | M3 Simple Wrench        | 1   |
|         | screwdriver | M3 Phillips screwdriver | 1   |

## 2. Assemble and Install

#### 2.1 Assembly steps

Note: 1. Before assembly, we need to use a screwdriver to peel off the protective paper of the acrylic structure;


| Step | 1                               | Assen       | nble the bracke<br>structure A | et and the | Tool                                | M3 Phillips screwdriver |
|------|---------------------------------|-------------|--------------------------------|------------|-------------------------------------|-------------------------|
|      | Part<br>Name                    | Quantity    | Unit                           |            | Pi                                  | icture                  |
|      | structure<br>A                  | 1           | PCS                            |            |                                     |                         |
| List | bracket                         | 4           | PCS                            |            | <b>\$ \$</b>                        | * *                     |
|      | M3<br>self-locki<br>ng nut      | 8           | PCS                            |            | 0000                                |                         |
|      | M3*10<br>round<br>head<br>screw | 8           | PCS                            |            | Gammannan<br>Gammannan<br>Gammannan |                         |
|      |                                 | Description | 1                              |            | D                                   | <b>D</b> emo            |




| List | Step 1<br>part   | 1           | PCS |      |
|------|--|-------------|-----|------|
|      | TT motor   | 4           | PCS |      |
|      | M3 nut   | 8           | PCS |      |
|      | M3*25M<br>M screw  | 8           | PCS |      |
|      |  | Description | 1   | Demo |
| A    | 1. Use M3*25 screws and M3 nuts to install the TT motor on the bracket of step 1 part (pay attention to the installation direction of the TT motor); |             |     |      |

| Step | 3   |          |      | 2 part with ure A | Tool | M3 Phillips screwdriver |
|------|---|----------|------|-------------------|------|-------------------------|
|      | Part<br>Name                                | Quantity | Unit |                   | Pi   | icture                  |
|      | Step 2<br>part                              | 1        | PCS  | (                 |      |                         |
| List | M3*10<br>double<br>pass<br>copper<br>column | 2        | PCS  |                   |      |                         |
|      | structure<br>B                              | 1        | PCS  |                   |      |                         |

|   | M3*8<br>round<br>screw  | 4  | PCS        |      |
|---|---|--|------------|------|
|   |   | Description                                      | on         | Demo |
| A | to fix the Mocolumn to so to the install copper column.  2. Use M3* | I3*10 double<br>structure A (p<br>llation direct | ion of the |      |
|   |   |  |            |      |




| Step | 4  | In                                | stall copper pi | llars | Tool   | M3 Phillips screwdriver   |
|------|--|-----------------------------------|-----------------|-------|--|---|
|      |  |                                   |                 |       |  |   |
|      | Part<br>Name                                 | Quantity                          | Unit            |       | Pi   | cture   |
|      | Step 3 part                                  | 1                                 | PCS             |       |  |   |
| List | M3*45<br>copper<br>pillar                    | 4                                 | PCS             |       |  |   |
|      | M3*30<br>copper<br>pillar                    | 4                                 | PCS             |       |  |   |
|      | M3*10<br>round<br>head<br>screw              | 8                                 | PCS             |       | Familianian  Familianianian  Familianianian  Familianianian  Familianianianian | Designation of the second |
|      |  | Description                       | 1               |       | D  | emo   |
| A    | fix the M3* M3*30 co structural m Pay attent | 45 copper copper columents A in t | curn;           |       |  |   |




|   | Structural D   | 1           | PCS |   |
|---|--|-------------|-----|---|
|   | M3 nut   | 2           | PCS |   |
|   | M3*8M<br>M screw   | 2           | PCS |   |
|   | M3*10<br>round<br>screw  | 4           | PCS |   |
|   | Battery<br>case  | 1           | PCS | TOTAL OF ALL OF |
|   |  | Description | n   | Demo  |
| A | A  1. Use M3*8 countersunk head screws to fix the 18650 battery case on the structure C (pay attention to the installation direction of the battery case);  2. Install the part completed in the |             |     |   |


previous step on the step 4 part;

3. Use M3\*10 round head screws to fix the structural part D on the M3\*45 copper column; (at the same time, pay attention to the combination of structural part C and structural part D)






| Г |  |   |   |      |
|---|--|---|---|------|
|   | M3*10<br>round<br>head<br>screw  | 8   | PCS   |      |
|   |  | Descriptio  | n   | Demo |
| A | screws to fit copper colutation to of the copper colutation to the so that you correspond in the future wires to parcircular hole.  Mark the wires of the to which wheel's motor the middle circular hole.  3. Use M3* to fix the particular hole. | tumn to the structural to the installation of the installation of the can know which where, and then one as through the le of structural to the interior of the can know where, and then one as through the le of structural to the interior of the can know which we have a structural to | double-pass ructure E (pay on direction  four motors nich wire heel's motor rganize the e middle al component  I head screws I in the |      |



Congratulations, a 4WD car chassis has been installed!



## 3. Make your suggestion and get support

THANK YOU for participating in this assemble document!

If you find errors, omissions or you have suggestions and/or questions about this document, please feel free to contact us: **cokoino@outlook.com** 

We will make every effort to make changes and correct errors as soon as feasibly possible and publish a revised version.

If you want to learn more about Arduino, Raspberry Pi, Smart Cars, Robotics and other interesting products in science and technology, please continue to visit our Amazon Store by search for "LK COKOINO" on Amazon. We will continue to launch fun, cost-effective, innovative and exciting products.

Thank you again for choosing Cokoino products.

#### LK COKOINO